

**NOTE:** ELCO Trimless items are best compatible with ELCO double wall housings. For use with single wall housing, access above ceiling is required. For best results, installation should be performed by a professional installer.

**CAUTION:** Disconnect power to the fixture (wall switch or breaker) before starting below instructions.

### Installation Instructions for Square & Round Trimless:

#### Step 1

After the trimless housing is installed, insert the proper spackle frame into the collar of the housing.

#### Step 2

Secure the spackle frame onto the ceiling by using the drywall screws in the four holes located on the corners of the spackle frame.

**Note:** Drywall screws must not be longer than 3/4".

#### Step 3

Apply plaster over the spackle frame without letting any of the plaster into the hole opening of the housing. Use provided cardboard cutout to cover the hole opening while plastering if necessary.

**Disclaimer:** Any plastering or ceiling work must be done by a professional drywall.

#### Step 4

Install Koto™ LED Module onto the trim part (trim must be compatible with spackle frame).

#### Step 5

Mate the connector on the Koto LED Module with the connector coming from the housing.

#### Step 6

Insert the LED module trimless assembly through the opening of the spackle frame until the clips fully engage. The opening edge of the reflector should be flush with the face of the spackle frame.

